

PANEL INSTALLATION

1. REMOVE ALL FOAM PROTECTORS.
2. DO NOT DROP THE PANELS ON ENDS, EDGES, OR CORNERS.
3. INSERT PANELS INTO TRACKS AND ADJUST.

HANDLE INSTALLATION (OPTIONAL)

1. LOCATE HANDLE 40" FROM FLOOR TO CENTER OF HANDLE PLACEMENT.
2. CLEAN MIRROR WITH ALCOHOL.
3. REMOVE TAPE PROTECTOR FROM BACK OF PULL.
4. ATTACH HANDLE AND PRESS.
5. (1) HANDLE PER PANEL IS PROVIDED.

